# **User Manual**

HDMI & AV Video 2 in 1 capture card



### PACKING LIST:

1:One capture card,

2:one AV cable,

3:one manual

### **Product Description**

#### Introduction:

This USB 2.0 capture card can capture both HDMI and AV audio and video signals, and preview and store them on a computer or smartphone. Suitable for standard and high-definition capture, teaching recording, network live broadcast, medical image capture, etc.



#### **Features:**

- Supports both HDMI and AV inputs;
- The maximum input resolution for HDMI interface is 4K@30;
- The maximum USB capture resolution is 1080P when HDMI signal is input;
- The maximum USB capture resolution is 576P when AV signal is input;
- Compatible with Windows, Android, and MacOS;
- Complies with UVC and UAC specifications;
- No external power supply required, small size, and easy to carry;

- Supports a variety of capture software such as VLC, OBS, Amcap, VHS, and Potplayer;
- [Wide compatibility with multiple systems]: The 4K PC capture card is compatible with Windows 7/8/10, Mac OS X 10.9 or higher, Linux and many other systems. Compatible with PS4, Nintendo Switch, camera, network camera, digital SLR camera, and real-time streaming on Twitter/Youtube/OBS/Potplayer.
- CVBS video input: support for NTSC and PAL formats, output: support for MJPEG and YUV422; in addition, it also supports external audio ADCs
- CVBS Capture Resolution: When CVBS is input, USB capture resolution supports 1080P30
  in MJPEG format, 480P and 576P in YUV format.

### **Specifications:**

| HDMI resolution   |
|---|
| AV resolution ······· PAL or NTSC   |
| Video input format 8/10/12 bit color depth  |
| Video output resolution Maximum output resolution is 1080P  |
| Video output format YUV, MJPEG  |
| HDMI input cable length… Less than 15m, AWG26 HDMI standard cable   |
| Maximum working current 0.4A/5V DC  |
| Operating temperature range (-10 to 55 $^{\circ}\!$ |
| Product length  |
| Product weight  |

### **Product Connection Images:**



## **HDMI** capture



# **AV** capture





## **Connection Operation:**

(Note: Before use, make sure to install capture software such as OBS studio, VLC, etc. If not, please download the capture software first.)


- 1: Connect the UHD or AV signal source to the HDMI input or AV interface of the USB capture card through 1 HDMI cable and 1 AV cable.
- 2: Connect the USB cable of the capture card to the USB port of the computer.

- 3: Capture operation steps (OBS): Open the software, add a new source, select "video capture device," set the screen size, select "studio mode" (dual window), click "start recording," as shown in the example below.
- Add a new source and select "video capture device" (HD select CY001-HD; AV select
  CY001-AV)






- 2. Set the screen size.
- 3. Select "Studio mode" (dual window).



4. Click "start recording."



**Note: Computer hardware requirements:** 

CPU: PC i5-3400 or above; NB i7-3537U2.0GHZ or above

Graphics card: PC NVIDIA GT530 or above;

Memory: 4G or above;